



## Stainless Steel Test Panel Tip Sheet

The following information is intended to help our customers understand the proper initial preparation, proper continuing maintenance, and retiring used test panels.

For the purpose of identification and traceability, Cheminstruments test panels are stenciled with a lot number and date on the back (“non-test” side) of the panel. A test panel certificate will be issued for every test panel order.

All Cheminstruments test panels meet the requirements as specified in the PSTC test methods manual Appendage B Section 2.6 and ASTM D 3330 Section 6.3. These methods specify type 304 stainless steel with a bright annealed finish. The content of the stainless steel complies with the specifications required by ASTM A666. The surface roughness shall be 38 nm +/- 12 nm (1.5 u” +/- 0.5 u”) arithmetical average deviation from the mean profile. The thickness shall be no less than 1.1 mm (0.043 in). The dimensions for a typical Peel Adhesion panel are 50 by 125 mm (2 by 5 inch) with the machine direction parallel to the 125 mm direction.

It is the customer’s responsibility to regularly inspect the test panels to comply with established standards and to continuously maintain the test panels in an effort to collect accurate test data.

### Initial Preparation for New Test Panels

1. New test panels are protected with a plastic film that should be removed as soon as they are received.
2. It is important that the new panel be cleaned after removal of the protective vinyl film. New panels have residual contaminants on the test surface from the finishing process as well as adhesive residue from the protective vinyl film.
3. All new panels should be cleaned by wiping in the machine direction with a strong solvent such as Methyl Ethyl Ketone or Acetone. Apply solvent to the testing surface in a fume hood or other well-ventilated area. Wipe with an absorbent, suitable lint free material which contain no additives dissolvable in the solvent of choice.
4. Place the panel in an oven at 350°F (~175°C) for about 1 hour.
5. The initial wash will remove some of the impurities and the heat exposure will bake off residual contaminants from the surface. After the panels have cooled, clean them again with n-Heptane and MEK to clean off any remaining residue.
6. At this point, we recommend using Contrex AP. The cleaner comes in powder form offered by Decon Labs. Follow safety indications of the container. Wear safety glasses and nitrile gloves at a minimum. Gloves also prevent fingerprints on the test surface. The powder was diluted as instructed on the container – 15 grams Contrex® powder/1900 milliliter DI Water – mix to assure all the powder is dissolved.
7. Use the solvent of your choice for 10 additional washes as outlined above in point number 3 to

SERVING  
INDUSTRY  
SINCE 1986

510 Commercial Drive  
Fairfield, OH 45014  
p: 513.860.1598  
f: 513.860.1597  
sales@cheminstruments.com  
[www.cheminstruments.com](http://www.cheminstruments.com)



## Stainless Steel Test Panel Tip Sheet

remove any additional contaminates. Refer to PSTC Appendage C or ASTM D 3330-00 (2010) Section 6.3 Panel, 7.0 Select Solvents and Section 11.1 for comprehensive cleaning instructions.

8. If panels still show contamination or smearing, repeat cleaning process with different solvent.

\*\*\* ChemInstruments performs steps 1-5 as a service for all Super Panels. The user must perform steps 6-8 upon receipt of all Super Panels.

### Continued Cleaning and Maintenance

1. When cleaning panels, ASTM D3330 states in paragraph 11.1, "Dispense one of the solvents listed in 7.2.1 onto the panel, wiping it to dryness with fresh absorbent cleaning material. Repeat for a total of three solvent washes. Final wipe shall be MEK or Acetone. The panel shall be allowed to dry at standard conditions for at least 10 minutes. If cleaned panel is not used within 10 hours, it should be cleaned again prior to use."
2. The following guidelines are recommended for routine cleaning based on the adhesive being tested:
  - a. Solvent Adhesive – use MEK, followed by Heptane, then MEK
  - b. Emulsion Adhesive – use Warm water sonicator, then MEK, followed by Heptane, then MEK
  - c. Silicone Adhesive – use Xylene, followed by Toluene
3. Handle the test panels by the edges whenever possible. This will help keep skin oils out of the testing area of the panels.
4. It is advisable to mark the "grip" end of each panel when using a tensile tester to do adhesion testing. One should avoid gathering data from a scratched or roughened surface.
5. Panels showing stains, discoloration, or many scratches are not acceptable. The useful life of a test panel is determined by the number of tests, cleaning, and storage conditions of the panel. The customer is responsible for inspecting and determining the suitability of a test panel prior to use.
6. If you stack your panels when not using them, put soft lint free tissues between the panels to avoid scratching the testing surface. ChemInstruments also manufactures a **Test Panel Holder** (TPH-200) for storing these panels in a vertical position.

### Retire Used Test Panels

1. Even with cautious care, test panels can become damaged from accidental scratches, drops, or difficult to clean adhesive applications (epoxy or cyanoacrylate type).
2. Panels showing stains, discoloration, or any scratches are not acceptable and should be replaced.
3. Test panels can be closely monitored in lab environments with limited personnel. Lab setting with several analysts and multiple shifts may require panel inspection by a quality staff member on a regular basis. A plan should be written based on the frequency of use and risk assigned to the product under test.